

1 Copyright (c) 2023 Dogwood Valley Press, LLC. Copying and posting without permission strictly prohibited.

2

3 Pressure measurement conversion example

4 Additional internal variable declarations:  
TmpR REAL temporary needed for calculation  
TmpR2 REAL temporary needed for calculation

Conversion Equation  
 $PT101\_PSI = (PT101\_Raw / 32000) * (100 - 15) + 15$

5 Convert pressure measurement to PSI

