

SP7-1 Pressure measurement conversion

Copyright (c) 2023 Dogwood Valley Press, LLC

Additional internal memory:

None

Equation to convert PT101_RAW into the pressure in PSI:

$$PT101_PSI = (PT101_RAW - 3277 / 13107.0) * 85.0 + 15.0$$

Current tank level
in inches

PT101_PSI

CPT

Compute
Dest

F12:2

0.0<

Expression (((I:3.0 - 3277.0) / 13107.0) * 85.0
)+ 15.0

END

0000

0001