



Copyright (c) 2011-2023 Dogwood Valley Press, LLC

Revised Drilling Station Control

Additional internal memory:

Tag	Data Type	
Run	BOOL	On while station running
Int_Reset	BOOL	Internal reset
Step_1 to Step_16	BOOL	Step-in-progress bits
Unclamp_Tmr	TIMER	Times unclamp of part carrier

Start/stop and initial start. During reset, prevent start




Step 1 Wait for first part



Step 2 Move part to Position 2.



Step 3 Move part to Position 3.



Step 4 Clamp Part

