

Copyright (c) 2011-2023 Dogwood Valley Press, LLC

Conveyor Transfer Station Control

Additional internal memory:

Tag	Data Type	
Run	BOOL	On while station running
Int_Reset	BOOL	Internal reset
Step_1 to Step_5	BOOL	Step-in-progress bits
Dly_Tmr	TIMER	Box travel delay after gate up

Start/stop and initial start.
During restart prevent start.





