1 Copyright (c) 2011 Dogwood Valley Press, LLC. Copying and posting without permission strictly prohibited.

2

3 Simulation

4 On reset, reset PROX and LS2

5 RESET_PB — LS2 RM; PROX RM

6 PROX simulation: Set when PROX off and for 4 secs.
Reset 3 secs after OILER_UP transitions off

7 TON Prox_O... IN Q PT ET 4000 — PROX — PROX SM

8 TON Prox_O... IN Q PT ET 3000 — OILER_UP — Prox_Off_T... (N) — Prox_Off_... — PROX RM

9 LS1 and LS2 simulation: Set LS1 when OILER_UP on for 3 sec. Reset when OILER_DOWN
Set LS2 when OILER_DOWN on for 3 sec. Reset when OILER_UP

10 TON LS1_Tmr IN Q PT ET 3000 — OILER_UP — LS1 SM; LS2 RM

11 TON LS2_Tmr IN Q PT ET 3000 — OILER_DO... — LS2 SM; LS1 RM