

Main [OB1]

Main Properties

General

Name	Main	Number	1	Type	OB
------	------	--------	---	------	----

Language	LAD	Numbering	Manual		
----------	-----	-----------	--------	--	--

Information

Title	SP5-5	Author		Comment	
-------	-------	--------	--	---------	--

Family		Version	0.1	User-defined ID	
--------	--	---------	-----	-----------------	--

Name	Data type	Default value
▼ Temp		
OB1_EV_CLASS	Byte	
OB1_SCAN_1	Byte	
OB1_PRIORITY	Byte	
OB1_OB_NUMBR	Byte	
OB1_RESERVED_1	Byte	
OB1_RESERVED_2	Byte	
OB1_PREV_CYCLE	Int	
OB1_MIN_CYCLE	Int	
OB1_MAX_CYCLE	Int	
OB1_DATE_TIME	Date_And_Time	
Constant		

Network 1: SP5-5


Copyright (c) 2011-2023 Dogwood Valley Press, LLC

Switch press counter

Additional internal memory:


Tag Address

Ctr1 %DB1 (IEC_COUNTER) Counts items



Network 2: Counts 20 presses of PB151

Counter resets itself at 20 so that more pb presses can be counted while PL612 is on.



Network 3: Pilot light control

When 20 have been counted, latch PL612.
When PB613 is activated, unlatch PL612.

