

GET_STEP [FC90]

GET_STEP Properties

General

Name	GET_STEP	Number	90	Type	FC
Language	SCL	Numbering	Manual		

Information

Title		Author		Comment	
Family		Version	0.1	User-defined ID	

Name	Data type	Default value
▼ Input		
StpNum	Int	
SArray	Array[0..63] of Bool	
▼ Output		
Out	Bool	
InOut		
Temp		
Constant		
▼ Return		
GET_STEP	Void	

```
0001 #Out := #SArray[#StpNum];
0002
```

SET_STEP [FC93]

SET_STEP Properties

General

Name	SET_STEP	Number	93	Type	FC
Language	SCL	Numbering	Manual		

Information

Title		Author		Comment	
Family		Version	0.1	User-defined ID	

Name	Data type	Default value
▼ Input		
In	Bool	
StpNum	Int	
Output		
▼ InOut		
SArray	Array[0..63] of Bool	
Temp		
Constant		
▼ Return		
SET_STEP	Void	

```
0001 #SArray[#StpNum] := #In;  
0002
```